

AVAIR

AV-5000Z SERIES SWITCHING POWER SUPPLY

INSTRUCTION

AV-5000Z series is lightweight, high performance, high efficiency, durable, switching power supply and with highly visible back light, easy to read dual meters .

Specification

Input voltage: AC 90~125 or AC 200~240 inside selectable

Output voltage : DC 0.0V~24V variable

Output voltage regulation : less than 1%

Ripple: less than 9mVp-p at rated load

Protection:

1 short protection: it will reduce the output voltage down to 0.1v Amps down to 0.4Amps and the warning led will light up

when short condition remove it will automatic restart the power supply to normal condition.

2 overload protection: same as above

3 over voltage protection(if over Dc16v):same as above

4 over temperature protection: AV-5000Z series has two stage over temperature protection function see attached Fig3.

Output current: AV-5035Z :Max DC24V 15A DC16V 27A DC12V~2V 35A


AV-5045Z :Max DC24V 20A DC16V 35A DC12V~2V 45A

Dimension :200(D)X172(W)65(H)mm

Weight : AV-5035Z 1.86Kg AV-5045Z 1.9Kg

Function Description

Fig 1. For AV-5000Z series only



1 Power indicator : Light up when the unit turn on.

2 Warning indicator: Light up when output terminal short or over load, over voltage(preset 16Dcv), component over hot.

3 Voltage adjust knob: Turn clockwise increase the output voltage , when at center position factory preset Dc 13.8v.

5 Amps indicator meter: Display the output current when connect any device.

6 Voltage indicator meter: Display the output voltage.

7 Output Socket: Dc output max 10 Amps


8 Output terminal: Negative polar of Dc output

9 Output terminal: Positive polar of Dc output

10 Ac input socket: Ac 90v~120v or Ac 200v~240v

11 Power switch: Turn the unit on or off

Fig 2. For AV-5000Z series only




Caution

- 1 This power supply is natively ground, always use the AC outlet with ground terminal.
- 2 Before replacing a fuse make sure you have unplug the Ac plug and never use unproperly fuse value.
- 3 Do not block the air convention slits to keep the efficient heat radiation.

Ampere

Voltage VS output Ampere



AVAIR ELECTRONICS CO.

NO.88 SAN TOE RD. SEC. 1 KAOSHIUNG ,TAIWAN
Phone:+886-7-7519135 Fax:+886-7-7512008
E-Mail:sales@avair.biz